

(1) Log into care.iadea.com

If the player is not on V. 1.1.0-47, hit F5 or refresh on your browser and log in.

Discover what IAdea products offer to



The image shows a login page for IAdeaCare. At the top, the text "Discover what IAdea products offer to" is partially visible. Below it is the IAdeaCare logo, with "IAdea" in a bold, black, sans-serif font and "Care" in a lighter, black, sans-serif font, followed by a square icon composed of four smaller squares. Below the logo are two input fields: the first contains the email address "johnny.chen@iadea.com" and the second contains a masked password ".....". To the left of the password field is a lock icon. Below the password field is a blue link that says "Forgot password?". There are two green buttons: the top one says "Login" and the bottom one says "Sign up". Below the buttons, the text "Version: 1.1.0-47" and "Release: 2019/10/15" is displayed. At the bottom of the page, the URL "www.IAdea.com" is shown, followed by a disclaimer: "This site is protected by reCAPTCHA and the Google Privacy Policy and Terms of Service apply."

IAdeaCare

johnny.chen@iadea.com

.....

[Forgot password?](#)

Login

or

Sign up

Version: 1.1.0-47
Release: 2019/10/15

www.IAdea.com

This site is protected by reCAPTCHA and the Google [Privacy Policy](#) and [Terms of Service](#) apply.

(2) If the page does not look correct, right click webpage and select Inspect.

The screenshot shows the IdeaCare web application interface. At the top left is the IdeaCare logo. Below it is a sidebar with icons for Home, Settings, LOG, and a document icon. The main content area features a control bar with buttons for 'Add/remove player', 'Advanced control', and refresh/refresh icons. Below the control bar is a search bar with a dropdown menu showing '10' and a search icon, and a search input field labeled 'Search by Player name ...'. A table of player models is displayed, with a right-click context menu open over the table. The context menu includes options like Back, Forward, Reload, Save as..., Print..., Cast..., Translate to English, AdBlock, Show Downloads, View page source, and Inspect. The table has a header 'Model' and contains rows with model names: XMP-7300, XMP-7300, and XDS-1078. Below the table, the text 'Last refresh time : 2019-10-15 10:20:30' is visible.

Model
XMP-7300
XMP-7300
XDS-1078

Last refresh time : 2019-10-15 10:20:30

(3) Then Right-Click the Refresh button and select Empty Cache and Hard Reload.

